



### FIELD SERVICEABLE PART LIST

DESCRIPTION	PART NUMBER
<b>A.</b> Install hardware	HK-USM1250
<b>B.</b> Handle base cap	RK-CFC-XX*
<b>C.</b> Hot & cold indicator ring	RK-4864-R&B
<b>D.</b> Contemporary handle	RK-CKFLH-XX*
<b>E.</b> Tension ring	RK-4861-XX*
<b>F.</b> Friction collar	RK-4911-RBR
<b>G.</b> Ball joint	RK-CBJ-RBR
<b>H.</b> Cartridge retainer nut	RK-4963-RBR
<b>I.</b> Cartridge	RK-PTC35

DESCRIPTION	PART NUMBER
<b>J.</b> Diverter	RK-KFD
<b>K.</b> O-ring #129	VEN-001-0129-00PC
<b>L.</b> Spout retainer nut	RK-4071-RBR
<b>M.</b> Spout Keeper	RK-4893-XX*
<b>N.</b> O-ring #16	VEN-001-0016-00PC
<b>O.</b> Spout	RK-3925SPT-XX*
<b>P.</b> Aerator & O-ring #14	RK-JR
<b>Q.</b> Spout Tip	RK-4789-XX*

*\*Replace XX with finish code\**