

CERAMIC HANDLE BUTTON REPLACEMENT

1. Find the notch (A) at the bottom of the handle button base (B). With your fingernail or small screwdriver, pry and remove the button base from the faucet handle (C). Some buttons may have a black o-ring (D) under the button. If so, remove and discard.

2. Scrape and remove any old glue or debris from the button base that may interfere with the adherence of the replacement button. Remove the wax paper flaps (E) from **BOTH** the top and bottom of the adhesive sticker (F) provided. Discard flaps. Place sticker inside handle button base and press to secure.

3. Align the compass logo as shown to ensure notch is at bottom of button base. Place ceramic button (G) inside button base and press to secure.

4. Press handle button back into faucet handle. Make sure compass logo is aligned properly.

★ MADE IN THE USA ★

1-888-304-0660 • 951-304-0520

www.waterstoneco.com

VEN-038-HBRS Rev. B