



GANTRY FAUCET SPRAY VALVE REPLACEMENT KIT

CONTEMPORARY MODEL #S 3700, 3710-12, 3710-18

TRADITIONAL MODEL #S 4400, 4410-12, 4410-18

BEFORE YOU BEGIN YOUR INSTALLATION:



Turn off water supply.

REQUIRED TOOLS:



Needle Nose Pliers

PARTS INCLUDED:

#RK-GSV (QTY. 2)
Gantry Spray Valve

1.

Turn off water supply. Slowly unscrew spray valve cap (A). Remove cap and spring (B).

B

A

2.

Using needle nose pliers, remove spray valve stem (C).

C

3.

You should have received two different spray valve stems. Look for the grooves on the side of the stems. There will be either one groove or two. Compare the grooves on the old stem you just removed and match to one of the new stems.

ONE GROOVE

OR

TWO GROOVES

4.

Insert the appropriate spray valve stem into spray nozzle. Place spring over stem head. Place cap over spring and hand tighten until snug. Turn water back on and check for leaks.

★ MADE IN THE USA ★

1-888-304-0660 • 951-304-0520

www.waterstoneco.com

VEN-038-GPSV Rev. C