PULLDOWN SPRAY FACE REPLACEMENT KIT

ALL TRADITIONAL AND CONTEMPORARY PLP PULLDOWN FAUCETS
W/ A LEVER SPRAYER

1.



Turn off water supply. Unscrew spray face (A).

2.



Remove spray face and bumper ring (B) and dispose.

3.



Assemble new spray components. Place Rubitz insert (D) into spray face (C). Place nozzle support (E) on top of Rubitz insert. Line up the posts of the nozzle support with the holes of the Rubitz insert for proper fit. Slide bumper ring (F) over top of spray face.

NOTE: *Contemporary version of nozzle support is slightly smaller than traditional.*



4.



Replace spray assemble. Screw spray face onto spray base (G) until snug. Turn on water and check for leaks.

★ MADE IN THE USA ★

1-888-304-0660 • 951-304-0520
www.waterstoneco.com